



LiFePO4 (LFP) Battery

Product manual



LFP5.42KWH51.2V-P65H2QT50

Contents

| | |
|--|-----------|
| 1 Important Safety Instructions | 1 |
| 2 General Information | 3 |
| 2.1 Appearance | 3 |
| 2.2 Product size | 5 |
| 3 Basic Information | 6 |
| 3.1 Interface definition | 6 |
| 3.2 Product features | 7 |
| 3.3 LCD color display | 8 |
| 4 Instructions | 11 |
| 4.1 Packing list..... | 11 |
| 4.1 Installation requirements | 12 |
| 4.3 Charging operation | 17 |
| 4.4 Discharge operation | 17 |
| 4.5 Description of battery parallel capacity and voltage | 18 |
| 5 Protection Features | 19 |
| 6 Specifications | 24 |
| 7 Precautions | 25 |
| 7.1 Maintenance precautions | 25 |
| 8 Disclaimers | 26 |

1 Important Safety Instructions

※ Thank you for choosing EPEVER Lithium Iron Phosphate (LFP) battery, please read this manual carefully before using this product.

※ It is strictly forbidden to install this product in harsh environments such as moisture, salt spray, corrosion, greasy, flammable and explosive, or a large amount of dust accumulation.

※ Please keep this product manual for future reference.



Precautions for work and storage

- a) Please keep the battery in a cool, dry place. The environment should be free of corrosive, explosive and insulation-damaging gases or conductive dust, and away from fire and heat sources and high pressure; It is forbidden to immerse the battery in water; Keep out of reach of children; Pay attention to anti-static electricity (static electricity may damage the battery protection circuit, causing battery damage).
- b) The battery should be safely fixed in a reasonable use of the environment, the connector must be reliably connected to avoid contact friction caused by arc and sparks.
- c) When handling the battery, please handle it gently to avoid mechanical vibration, collision and pressure shock. Otherwise, it may cause internal short circuit of the battery, resulting in high temperature and fire.
- d) Do not short-circuit the positive and negative poles of the battery, and do not disassemble or assemble the battery to avoid danger.
- e) Please keep the battery in a semi-charged state (40%~80% SOC is appropriate). Please wrap the battery with non-conductive materials to avoid direct metal contact with the battery, which may cause battery damage.
- f) Please dispose of waste batteries safely and properly, and do not put them into fire or liquid.
- g) This battery cannot be used in series.



Danger warning

- a) It is strictly forbidden to crush, drop, collide, puncture, burn and other destructive behaviors on the battery.
- b) It is forbidden to disassemble and assemble the battery. Improper disassembly and assembly may damage the protective function of the battery, resulting in deformation, heating, smoke or combustion of the battery.
- c) It is forbidden to short circuit the battery. It is prohibited to connect the positive and negative electrodes of the battery with conductive materials; Do not store or transport the battery with the conductor to avoid battery damage due to short circuit

d) It is forbidden to heat and incinerate batteries. It may melt battery components, lose safety features, or burn electrolyte. Overheating can deform, heat, smoke, or burn the battery.





Emergency treatment method

- a) When the electrolyte leaks, avoid skin and eye contact with the electrolyte. In case of contact, wash immediately with plenty of water and seek help from a doctor. It is forbidden for any person or animal to swallow any part of the battery or the substances contained in the battery.
- b) b) If the battery is seriously deformed or the electrolyte leaks due to collision and extrusion, the battery should be placed in the explosion-proof box or an open place, and the personnel should be evacuated quickly if conditions permit,.
- c) If the battery catches fire during use or storage, use a high-pressure water cannon to extinguish the fire under the condition of ensuring personal safety.
- d) d) If the battery catches fire during charging, be sure to turn off the charger as soon as possible before executing the next fire extinguishing action.

2 General Information


2.1 Appearance





| | | | |
|---|-------------------------|---|---|
| A | Weak-current switch | G | Negative connector |
| B | Metal handle | H | PC upper computer communication interface |
| C | Wall mounting bracket | I | Inverter communication interface |
| D | LCD color screen | J | Parallel communication interface |
| E | Positive connector | K | Parallel communication interface |
| F | Pressure reducing value | L | Grounding screw interface |

2.2 Product size




3 Basic Information

3.1 Interface definition

(1) The RS232 communication interface pin are defined as follows, and the RJ11 communication interface is used to connect the upper computer of the lithium battery PC.


| RJ11 Pin | RJ11 Definition |
|----------|-----------------|
| 1、 2、 6 | NC |
| 3 | TX |
| 4 | RX |
| 5 | GND |



(RJ11)

(2) The pins of the CAN/RS485 communication interface are defined as follows, and the RJ45 communication interface is used for the communication connection between the lithium battery and the inverter host.


| Pin No | RJ45 Definition |
|--------|-----------------|
| 1 | RS485-B |
| 2 | RS485-A |
| 3 | GND |
| 4 | CAN-H |
| 5 | CAN-L |
| 6 | NC |
| 7 | RS485-A |
| 8 | RS485-B |



(RJ45)

(3) The DIP communication interface pin is defined as follows: RJ45 communication interface is used for parallel communication between lithium battery and lithium battery parallel machine.


| Pin No | RJ45 Definition |
|--------|-----------------|
| 1 | RS485-B |
| 2 | RS485-A |
| 3 | GND |
| 4 | GND |
| 5 | OP+ |
| 6 | NC |
| 7 | RS485-A |
| 8 | RS485-B |



(RJ45)

(4) The BMS communication interface pins are defined as follows, and the RJ45 communication interface is used for the communication connection between lithium battery and lithium battery parallel machine.

| Pin No | RJ45 Definition |
|--------|-----------------|
| 1 | RS485-B |
| 2 | RS485-A |
| 3 | GND |
| 4 | GND |
| 5 | UP-IN |
| 6 | NC |
| 7 | RS485-A |
| 8 | RS485-B |




3.2 Product features

- It has the function of single voltage and overall voltage detection, over-voltage and under-voltage alarm and protection
- It has the functions of charge and discharge current detection, alarm and protection
- It has the function of cell, environment and PCB temperature detection, and can alarm and protect when charging and discharging at high and low temperature
- It has the function of detection and protection of output short circuit
- With the battery SOC calculation, charge and discharge cycle calculation function
- With a charge balancing function, reduce the charging current of the high-voltage cell (the reduced current is the balance current set by the BMS)
- With LED indicator function, indicating the current battery SOC, battery fault status, operating status, etc
- BMS manual and automatic sleep function
- With charge current limiting function
- With history storage function (not less than 500 storage capacity)
- With RS485 communication function, real-time monitoring of BMS and battery status
- The two-stage over-current protection function of discharge has different response speed to different current values, which protects the battery more reliably.




3.3 LCD color display

Interface introduction:


➤ Main state page



Icon Introduction:

| | |
|---|---|
|  | Main Menu Icon: Tap to enter the main menu HOME interface |
|  | Main State Icon: Click to enter the Main State interface |
|  | Parallel Data Icon: Click to enter the Parallel Data page |

➤ HOME page



② Menu

| Menu | | | | |
|--|---------------|-------------|--|---|
| Main state page | SOC (Total) | / | / | |
| | Current | / | / | |
| | Voltage | / | / | |
| | BMS INFO | / | / | |
| | Warranty | / | / | |
| | Parallel data | SOC (Each) | / | / |
| | | Current | / | / |
| | | Voltage | / | / |
| BMS Information | | / | / | |
| Home | PACK Info | Voltage | Voltage of Cell 01 | |
| | | | Voltage of Cell 02 | |
| | | | | |
| | | | Voltage of Cell 16 | |
| | | Temperature | NT1 | |
| | | | NT2 | |
| | | | NT3 | |
| | | | NT4 | |
| | Mos-T | | | |
| | ENV-T | | | |
| | BMS Status | Warning | / | |
| | | Protect | / | |
| | | Fault | / | |
| | | Record | / | |
| | PROTOCOL | CAN | GOOD WE PROTOCOL | |
| | | | LV BMS Protocol (CAN) for Solar Inverter Family EN-V 1.5 | |
| PYLON PROTOCOL 2.0 | | | | |
| PYLON CAN bus protocol V 2.0.420211122 | | | | |
| SMA PROTOCOL | | | | |
| SMAF SS-Connecting Bat-TI-en-20W | | | | |
| GROW ATT-PROTOCOL | | | | |












| | | | |
|--|----|--------------------|---|
| | | | Growatt BMS CAN Bus-protocol-low-voltage |
| | | RS485 | USER-485-voltron |
| | | | Voltronic Inverter and BMS 485 communication protocol 20200325 |
| | | | PYLON |
| | | | RS 485-protocol-pylon-low-voltag |
| | | | Luxpowertek Battery Protocol RS 485-V 01 |
| | 系统 | Language select | English |
| | | | Chinese |
| | | | (Traditional Chinese) |
| | | PACK SN | / |
| | | (BLUETOOTH SN) | / |

Note: The protocol list is access from the BMS motherboard. The following is an example: Based on the built-in list of each BMS motherboard, the first time you change the protocol, you need to enter the permission password, and the initial password is 123456. Exit the agreement interface, and the permission takes effect; If you modify the agreement again, you need to verify the permissions again.

4 Instructions

4.1 Packing list


Before unpacking, please check the outside of the battery for damage to the packaging and check the model of the battery. If there is any abnormality, please do not open the package and contact the after-sales service center as soon as possible. After unpacking the battery, please check whether the product is complete according to the packaging information. If you have any questions, please contact the after-sales service center as soon as possible.

| | | |
|--|--|---|
|  <p>X1 Lithium battery</p> |  <p>X1 Wall mounting bracket</p> |  <p>X1 RS485 communication cable</p> |
|  <p>X1 Positive output power cable</p> |  <p>X1 Negative output power cable</p> |  <p>X1 Battery pack parallel communication cable</p> |
|  <p>X1 Positive connector quick plug</p> |  <p>X1 Negative connector quick plug</p> |  <p>X1 USB-A to RS232 communication cable</p> |
|  <p>X4 M8 x 60 expansion bolt</p> |  <p>X2 M8 x 12 bolt group</p> |  <p>X2 RNB22-8 wiring terminal</p> |


4.1 Installation requirements

a. Space installation distance

Master and check the performance of all tools and devices to ensure safety before using them.



The left and right distance between battery packs is recommended. Minimize the distance as much as possible.



b. Installation environment


- The battery works best at 20~40°C.
- Avoid installation in environments with direct high temperature and rain.
- Avoid installation close to high temperature heat source or low temperature cold source.
- Avoid installation in places where the ambient temperature changes drastically.
- Avoid installation in strong interference environments.
- Avoid installation in places where children can enter.
- Avoid installation in places where water is likely to accumulate.
- It is forbidden to place flammable and explosive materials around the equipment.

c. Prepare tools


| | | | | |
|--|---|---|---|---|
|  |  |  |  |  |
| Hammer Drill | Rubber Hammer | Claw Safety Hammer | Insulated Cross Screwdriver | Insulated Slotted Screwdriver |
|  |  |  |  |  |
| Spirit Level | Tape Ruler | Insulated Tape | Dustproof Cover | Protective Glasses |
|  |  |  |  |  |
| Utility Knife | Wire Stripper | Diagonal Pliers | MC4 Crimper | Multimeter |
|  |  |  | | |
| AC/DC Clamp-On Ammeter | Marker Pen | Electric Screwdriver | | |

d. Space installation requirements

1. Make the mounting bracket close to the wall (level correction), mark the screw holes with a marker, and then remove the mounting bracket.



2. Use a hammer drill to drill a hole in the wall (diameter:10mm, depth: 65mm), insert the M8 expansion screw and tighten it.




3. Lift the lithium battery vertically and align it with the mounting bracket slots.


4. Push the lithium battery horizontally into the slot of the wall mounting bracket.

5. Let go slowly and allow the lithium battery to snap into the wall mounting bracket.

e. Wiring diagram



- Positive output power cable (1500mm)
- Negative output power cable (1500mm)
- RS485 communication cable (1500mm)
- Lithium battery positive parallel power cable
- Lithium battery negative parallel power cable
- Lithium battery parallel communication cable (DIP~BMS) (1200mm)



- Positive output power cable (1500mm)
- Negative output power cable (1500mm)
- RS485 communication cable (1500mm)



Warning


1. For operational safety and compliance, please disconnect the communication and cable link with the inverter when storing the battery.
2. During the handling and installation of the battery, it is recommended to wear safety helmets, goggles, protective shoes and other safety equipment suitable for the work to prevent accidental injury;
3. All wiring must be carried out by professionals. With the right cables, the battery connection is essential for the safe and efficient operation of the system. In order to reduce the risk, please use the cable provided by our company, or our recommended cable specifications.

4.3 Charging operation

1. Check before charging.

- Inspect the appearance of the battery and inverter or other connected equipment to ensure that the power cord and all wiring harnesses are connected.
- Make sure the power supply meets the specification requirements for the battery.

2. Turn off the inverter or other equipment, connect the positive and negative terminals of the battery, and connect the communication cable normally.

 **Warning: Before connecting the battery, ensure that the positive and negative terminals are connected. Do not reverse connect.**

3. Connect the charger to the power supply and turn on the charger.

4. Start the battery, the POWER indicator is on, and the SOC indicator flashes to start charging normally.

● **Standard Charging:**


First, charge the battery to 57.6V with a constant current of 20A (0.2C), and then charge to 5A (0.05C) with a constant voltage of 57.6V.

Note: All tests stated in this document shall be performed at 25±2°C.

4.4 Discharge operation

1. Before discharging, check whether the load and equipment are turned off.

2. Properly connect the positive and negative terminals of the battery to the load/inverter or other equipment.

 **Warning: Before connecting the load and equipment, please confirm the positive and negative wiring of the battery, and prohibit reverse connection.**

3. Turn on the load/inverter or other device.

4. Start the battery. The POWER indicator is steady on, the RUN indicator is on for 0.5 seconds, and the discharge starts for 1.5 seconds.


Standard discharge:

After the battery is standard charged, discharging the battery with a constant current of 20A (0.2C) till the battery voltage drops to 41.6V.

Note: All tests stated in this document shall be performed at 25±2°C.

Precautions for charging and discharging operation:

- a) When the temperature is high ($\geq 35^{\circ}\text{C}$) in summer, the battery should not be charged more than 0.5C during the day, and it is recommended to stand for more than 30 minutes in the middle of the charge-discharge conversion to avoid the battery being used often in a high-temperature environment (a high-temperature environment will affect the battery life).
- b) When the temperature is low ($< 0^{\circ}\text{C}$) in winter, the depth of battery discharge $< 70\%$ to avoid over-discharge of the battery caused by too low temperature and affect the battery life.

 **Warning: This lithium battery should only be used with a manufacturer or manufacturer-matched compatible inverter or other equipment. When the lithium battery does not communicate with the inverter or other equipment, it is forbidden to use the lithium battery.**

4.5 Description of battery parallel capacity and voltage

| Capacity | Number of battery parallel groups | Maximum charging voltage | Discharge cut-off voltage |
|----------|-----------------------------------|--------------------------|---------------------------|
| 212Ah | 2 groups | 57.6V | 41.6V |
| 318Ah | 3 groups | 57.6V | 41.6V |
| 424Ah | 4 groups | 57.6V | 41.6V |
| 530AH | 5 groups | 57.6V | 41.6V |
| 636Ah | 6 groups | 57.6V | 41.6V |
| 742Ah | 7 groups | 57.6V | 41.6V |
| 848Ah | 8 groups | 57.6V | 41.6V |

5 Protection Features

| No | Item | Factory default parameter | Set state | Notes |
|----|---------------------------------------|--|---------------------------------|----------|
| 1 | Cell overcharge protection | Cell overcharge alarm voltage | 3600mV | settable |
| | | Cell overcharge protection voltage | 3650mV | settable |
| | | Cell overcharge protection delay | 1.0S | settable |
| | Cell over-voltage protection release | Cell overcharge protection voltage | 3380mV | settable |
| | | SOC release | SOC<96% | settable |
| | | Discharge release | Discharge current>2A | |
| 2 | Cell over-discharge protection | Cell over-discharge alarm voltage | 3380mV | settable |
| | | Cell over-discharge protection voltage | 3380mV | settable |
| | | Cell over-discharge protection delay | 1.0S | settable |
| | Cell over-discharge release | Cell over-discharge protection release voltage | 2950mV | settable |
| | | Release on charge | Plug in the charger to activate | |
| | | | | |
| 3 | Battery overcharge protection | Battery overcharge alarm voltage | 57.6V | settable |
| | | Battery overcharge protection voltage | 58.4V | settable |
| | | Battery overcharge protection delay | 1.0S | settable |
| | Battery overcharge protection release | Battery overcharge protection release voltage | 54V | settable |
| | | SOC release | SOC<96% | settable |
| | | Discharge release | Discharge current>2A | |
| | | | | |

| | | | | | |
|---|---|---|---------------------------------------|----------|--|
| 4 | Overall over-discharge protection | Battery over-discharge alarm voltage | 44.8V | settable | |
| | | Battery over-discharge protection voltage | 43.2V | settable | |
| | | Battery over-discharge protection voltage delay | 1.0S | settable | |
| | Battery over-discharge protection release | Battery over-discharge protection release voltage | 47.2V | settable | |
| | | Release on charge | Plug in the charger to activate | | |
| 5 | Charge over-current protection | Charging over-current alarm current | 105A | settable | If the status is locked for 10 consecutive times, it cannot be automatically unlocked |
| | | Charging over-current protects the current | 110A | settable | |
| | | Charging over-current protection delay | 1.0S | settable | |
| | Charge over-current protection release | Automatic release | Automatically disconnects after 1mins | | |
| | | Discharge release | Discharge current > 1A | | |
| 6 | Discharge over-current 1 protection | Discharge over-current 1 alarm current | 105A | settable | Appearing 10 times in a row will lock the state and will no longer be automatically disconnect |
| | | Discharge over-current 1 Protects current | 110A | settable | |

| | | | | | |
|----|---|---|---|----------|--|
| | | Discharge over-current 1 Protection delay | 1.0S | settable | |
| | Discharge over-current 1 protection release | Automatic disconnect | Automatically disconnects after 1 minute | | |
| 7 | Discharge over-current 2 | Protection current | > 150A | settable | It can be set 10 consecutive occurrences to lock the state without automatically disconnecting |
| | | Protection delay | 500mS | settable | |
| | Discharge over-current 2 protection release | Automatic disconnect | Automatically disconnects after 1 minute | | |
| | | Charge disconnect | Discharge current > 1A | | |
| 8 | Short circuit protection | Short-circuit protection function | Available | | |
| | | Short-circuit release | When there is charging, the short circuit protection is removed | | |
| | | | After the load is removed, it is automatically removed | | |
| 9 | MOS high temperature protection | Alarm temperature | 90° C | settable | |
| | | Protective temperature | 115° C | settable | |
| | | Release temperature | 85° C | settable | |
| 10 | Cell temperature protection | Charge low temperature alarm | 5°C | settable | |
| | | Charge low temperature protection | 0°C | settable | |
| | | Charge low temperature protection release | 5°C | settable | |
| | | Charging high temperature alarm | 60°C | settable | |

| | | | | | |
|----|---------------------------|--|-------|----------|--|
| | | Charging high temperature protection | 65°C | settable | |
| | | Charge high temperature protection release | 55°C | settable | |
| | | Discharge low temperature alarm | -15°C | settable | |
| | | Low temperature discharge protection | -20°C | settable | |
| | | Discharge low temperature protection release | -15°C | settable | |
| | | High discharge temperature alarm | 65°C | settable | |
| | | Discharge high temperature protection | 70°C | settable | |
| | | Discharge high temperature protection release | 60°C | settable | |
| 11 | Ambient temperature alarm | Ambient low temperature alarm | -15°C | settable | |
| | | Ambient low temperature protection | -20°C | settable | |
| | | Environmental low temperature protection release | -15°C | settable | |
| | | Ambient high temperature alarm | 65°C | settable | |

| | | | | | |
|----|-------------------|---|-------------------------|----------|--|
| | | Ambient high temperature protection | 75°C | settable | |
| | | Ambient high temperature protection release | 65°C | settable | |
| 12 | Low battery alarm | Low battery alarm condition | SOC<5% | settable | No alarm when charging |
| 13 | Sleep function | Sleep voltage | 3150mV | settable | |
| | | Delay time | 5min | settable | |
| | | Cell voltage difference | voltage difference > 1V | settable | Charging and discharging are not allowed |
| 14 | Full charge | Full charge voltage | > 56V | settable | When both conditions are met, stop charging and update the SOC to 100% |
| | | Cut-off current | < 2A | settable | |

(Note: Unless otherwise specified, the above parameters are tested at 25°C ambient temperature.)

6 Specifications

| Parameter | LFP5.42KWH51.2V-P65H2QT50 |
|------------------------------|--|
| Battery Type | LiFePO ₄ |
| Nominal Voltage | 51.2V |
| Nominal Capacity | 106Ah |
| Energy | 5427Wh |
| Continuous Discharge Current | 50A |
| Charge Cut-off Voltage | 57.6V |
| Discharge Cut-off Voltage | 41.6V |
| Maximum Charge Current | 50A |
| Maximum Discharge Current | 100A@30min |
| Peak Discharge Current | 120A@10S |
| Recommend Discharge Current | 50A |
| Open-circuit Voltage | 50.88~53.6V |
| Communication | RS485 RS232 CAN |
| Display | LCD |
| Cycle Life | >5000 times (0.5C charge&discharge 80%DOD @25°C) |
| Number of series/parallel | Max 8 battery packs in parallel |
| Certification | UN38.3 MSDS IEC62619 ROHS |
| Charge&Discharge Temperature | Charge: 0°C~+55°C Discharge: -20°C~+60°C |
| Storage Temperature Range | -5°C~+0°C/35°C~+45°C (≤2month); 5°C~+35°C (≤3 months, Optimum storage temperature); 15°C~+35°C (≤6 months) |
| Relative Humidity | 60%±20% RH |
| Connect Terminal | Quick-plug |
| Dimension (L x W x H) | 470mm*190mm*600mm |
| Net Weight | 47.6±0.5kg |
| IP Class | IP65 |
| Warranty | 3 years (See warranty agreement for details) |

① Repeat the operation method of standard charging and standard discharge 3 times, and take the third result as the initial capacity of the battery.

② When the battery is stored for more than 3 months, the storage voltage should be maintained at 52~53.6V.

③ For long-term storage, charge at least once every 3 months (no less than 30 minutes@0.2C).

7 Precautions

7.1 Maintenance precautions

| Item | Cycle |
|---|----------|
| If the battery is not in use, it needs to be fully charged and discharged to 50%. | 3 months |
| Check whether the wall bracket installation is loose. Please tighten the appropriate position if available. | 6 months |
| Check the casing for damage. If damaged, please repair or contact after-sales service center. | 6 months |
| Check exposed wires for wear and tear. If the cable is worn, replace the appropriate cable or contact the service center. | 6 months |
| Check for debris buildup around the battery. Clean it to prevent heat dissipation of the battery. | 6 months |
| Check water or pests to avoid long-term intrusion and damage to the battery. | 6 months |



Warning

1. If you find any problems that may affect the battery or the battery and energy storage system, please contact the after-sales service department, disassembly is strictly prohibited.
2. If you find that the copper wire inside the conductive wire is exposed, please strictly prohibit touching it due to the danger of high voltage. Please contact the after-sales personnel, disassembly is strictly prohibited.
3. If there are other emergencies, please contact the after-sales personnel first, operate under the guidance of the after-sales personnel, or wait for the after-sales personnel to operate on site.

8 Disclaimers

The warranty does not apply to the following conditions:

- Damage caused by improper use or inappropriate environments (It is strictly forbidden to install the Energy Storage System in the humid, salt spray, corrosive, greasy, flammable, explosive, dust accumulative or other harsh environments).
- The actual current/voltage/power exceeds the limit value of the Energy Storage System.
- Damage caused by working temperature exceeding the rated temperature range.
- Electric arc, fire, explosion and other accidents caused by failure to follow the Energy Storage System labels or manual instructions.
- Unauthorized disassembly and maintenance of the Energy Storage System.
- Damage caused by force majeure such as lightning strikes, rainstorms, mountain torrents and Utility failures.
- Damage occurred during transportation or loading/unloading the Energy Storage System.

Any changes without prior notice! Version number: V1.1



SolarV GmbH

Tel: +4961969076877

E-mail: info@solarv.de

Website: www.solarv.de