




INSTALLATION AND MAINTENANCE MANUAL

APENDIX | PICTURES



HPWH 3.2 100l
HPWH 3.2 150l




fig.0

OK !



fig.1

NOT OK !




fig.2




fig.3

OK !




fig.4

NOT OK !




fig.5




fig.6




fig.7




fig.8






fig.9






fig.12




fig.12a




fig.16




fig.16a





fig.16d






fig.13




fig.14




fig.15





fig. 17a






fig.17




fig.18




fig.19




fig.20




fig.21




fig.22




fig.22a

