




INSTALLATION AND MAINTENANCE MANUAL

APENDIX | PICTURES



HPWH 3.2 100l
HPWH 3.2 150l




fig.0

OK !



fig.1

NOT OK !




fig.2




fig.3

OK !




fig.4

NOT OK !




fig.5




fig.6




fig.7




fig.8







fig.9






fig.12




fig.12a




fig.16




fig.16a















fig.16d










fig.23a




fig.23

